



Try it-You'll like it!

www.ezhidewire.com

ONLY SCISSORS REQUIRED



1. Measure & Cut to desired size



2. Fold each crease completely in half



3. Peel outer (white) tape and adhere in desired position.



4. Place cables and wires inside and peel (tan) tape.



5. Seal EZ HIDEWIRE channel with cable and wires inside.

Important Notice

For safe use, electrical wires should not occupy more than 50% of the enclosed space within the product's channel. It is recommended that you test a small surface area before applying EZ HIDEWIRE. It can be removed easily from most surfaces but may permanently adhere to loose paint and drywall surfaces. Before using this product, you must determine if it is suitable for your intended application. You assume all risks and liability associated with its use.



#5075 White $1/2$ " x $3/4$ " x 8 ft.

#50112 White $1/2$ " x $1 1/8$ " x 8 ft.

